

LUMACURVE XTL UPGRADE KIT PARTS LIST




XTL Upgrade Kit Parts List
All other components grayed out.



XTL Upgrade Kit comes all-inclusive for changing out your old lighting system (with a handy handle!)

Item	Description
1.	340/345 Turn Fasteners
2.	*CLT-2 Cover
3.	*CLT-3 Base
4.	*CLT-4 End Panel
5.	*CLT-5 Legend Panel ¹
6.	*CLT-6 Multi-Mode Insert
6A.	*CLT-6A Panel Spacer ²
7.	*7-A Face Insert Channel ¹
8.	*8-A Lamp Socket Channel
9.	XTL Quartz XTL 20W Quartz Lamp
10.	E400A Lampholder
11.	480 Cable Clamp
12.	420 Terminal Strip
13.	420 Terminal Strip (section)
14A.	E411 Capacitor for E410
14B.	E611 Capacitor for E610
15A.	E410 PCB Controller, 50V (1-4 lamps)
15B.	E610 PCB Controller, 75V (1-8 lamps)
16.	E540 Bridge Rectifier 35A/1000V
17.	CLT-19 Tether
18.	130 Slipfitter
19.	*140 Frangible Coupling (6" long)
20.	430 Cord & Plug
21.	15 Floor Flange
22.	E416 Surge Protector



One lamp systems only require:

E550 Resistor 3 OHM 25w